



Show PM-06: 6 zone paging microphone for use with the 6 zone amplifier Show PS-4806. It features RCA input for external audio source and can be connected to the amplifier via cat5e cable which allows the mic to be installed more than 100m away from the amplifiers. The PM-06 also has a built-in chime function and a USB port (for connection to PC) through which chime tone can be modified. It can launch up to 6 messages stored in the PS main frame and controls over Play / Stop / Repeat functions.

#### Features

- Work with PS-4806
- Slave / Master Mode
- Paging up to 6 zones

#### Specifications

- Front Controls:
  - Push to talk switches for Zones 1-6, Push to talk switch ALL ZONE
  - Message bank switch x 6
  - Message START/STOP, REPEAT/STOP switches

- LED indicators: Green (Power), Yellow (Send), Red (Busy)
  - Rear Controls:
    - USB port for Chime editing
    - Selector CH1 / PROG
    - Dip Switches for Slave and Priority ON/OFF
    - Audio Out Volume
  - Aux In (-10dB ~ 0dB)
  - Output: RJ-45 for connection to PS4806
  - Link: RJ-45 for connection to two additional PM-06
- PDF